



Pneumatic Torque
Tool - Single Speed



Impact Sockets



Wheel Tools



Battery Tools



Nose Extensions



Mill Liner Tools



PSI	350	700	1000	1400	2000	2500	3000	3400	5000
19		150	200	300					
20									
21				350					
22		175			500				
23									
24			250	400					
25	100	200					1,000	1,500	
26					600				
27				450				1,100	1,600
28		225	300						
29									1,700
30				500	800		1,200	1,800	
31	125	250		700					
32							1,300	1,900	
33		350	550		900				
34		275		800			1,400	2,000	
35			600					2,100	
36									
37	150				1000		1,500	2,200	
38		300	400	650	900				
39							1,600	2,300	
40						1100		2,400	
41				700			1,700		
42	325	450		1000				2,500	
43	175		750						
44						1200	1,800	2,600	
45		350						2,700	
46			800	1100			1,900		
47			500		1300			2,800	
48		375		850				2,900	
49	200				1200		2,000		
50								3,000	
51		400	550	900		1400	2,100		
52								3,100	
53									
54			950	1300	1500		2,200	3,200	
55		425							
56	225		600				2,300	3,300	
57			1000					3,400	
58				1400	1600			3,500	
59									
60		450		1050			2,400		
61			650					3,600	
62					1500	1700	2,500		
63	250			1100				3,700	
64		475					2,600		
65			700		1800			3,800	
66				1150	1600			3,900	
67							2,700		
68		500		1200				4,000	
69						1900			
70			750		1700		2,800	4,100	
71	275	525			1250				
72						2000		4,200	
73							2,900		
74					1800			4,300	
75		550		1300					
76			800			2100	3,000	4,400	
77									
78	300	575			1900			4,500	
79				1350		2200	3,100		
80								4,600	
81									
82		600		1400	2000	2300		4,700	
83				850			3,200		
84									
85		625			2400			4,800	
86		325					3,300		
87						2500		4,900	
88									
89		650	900				3,400	5,000	
90									
91									
92		675							
93		350		950					
94									
95									
96		700							
97									
98									
99		1000							

RAD TORQUE CHART

Note, This chart only offers manufactures torque readings. All Pneumatic Torque tools require individual torque calibration. **Note this torque chart is only for single speed models.**

To Set Torque

To set the torque output adjust the regulator to required PSI from the torque chart. Depress the trigger on torque gun.

Ensure the tool is "Free Running", Spinning and un-loaded while setting pressure. Do not use tool direct from main air lines. The regulator, oiler and water trap must be in line.

Air Flow / Pressure

Ensure the air flow from your compressor is maintained over 90 psi and over 30 cfm.

Tightening or Loosening

To change the tool from tightening to loosening switch the direction lever across. Located in gun Pistol Grip.

Torque Calibration

All tools should be calibrated at least 6 Monthly.

HIRE

Ace offer all RAD Torque Nut Runners for hire. Ace are authorised RAD Distributors.

www.aceindustrial.com.au/rad

Contact

PH - 08 9446 5577
MOB - 0411 878 345
FAX - 08 9446 6586

www.aceindustrial.com.au